
Antenna Impedance

To transfer all available transmitter

power to the antenna, we must make

the reflected power = 0.



i.e. Pt = Part + Pret

oo make Pref = 0, so that &

Pant = Pt

To accomplish this, ZA must be matched?

ZA = Zo

Q: Huh?? Zo is a real values ou Za = Zo is a resistor!?!

=7 It would seem that a resistor would make a lousy antenna! But, think about this. A resistor closs not reflect power because it can absorb power. Reactive elements cannot absorb power, so power is reflected entirely. Antennas absorb power as well; the difference is that antennas radiate +his absorbed power, while a resistor converts it to heat. Q: Does this mean that antennus reflect no power?? A: No! In general, antennas bothet reflect and absorb power. i.e. ZA hus both u real (resistive) and imaginary (reactive) component. => Z1 = RA + 1XA

30 Circuit model is ? J X(w) 20 Note antenna input impedance, like other antenna parameters, is generally frequency dependent Q: So how do we eliminate (or, at least minimize) the reflected power ?? All Design the centenne such that RA = 20 (e.g. 50 12, 75 12, 300 12), and operate at frequency w such that X(w) = 0. => == == == == == AZ: Implement a matching network! matchnetwork